



SEAT BELT BRACKET COVER INSTRUCTIONS

Rev. B

Effective: 31-DEC-2015

Unobt ainium Supply Co. 523 Longley Rd Groton, MA 01450 978.448.2110 www.UnobtainiumSupply.com

SEAT BELT BRACKET COVER INSTRUCTIONS:

I've found that the bracket diameter varies, to avoid breaking your new cover, please do the following:

- 1. Check to see if you need to open the notches where the cover slips over the bracket so it won't get stressed going on. It should slip easily onto the bracket with only a very light amount of friction.
- 2. If it doesn't go on easily, enlarge the bracket notches so it's a slip fit on the bracket.

If you have it, use your original seat belt cover as a guide.

A small round or half-round file works great for this, alternatively, use a sharp knife.

BTW, This plastic can be heat softened. However, it takes a lot of heat to soften it, a hot day won't do it. To soften it you have to put it in boiling water, or heat some oil up to about 240F. On the plus side, the cover won't warp on a hot day.